

Transjet Opaque

Application Instructions

For dark-colored cotton, polyester
& poly/cotton blends

Use Transjet Opaque inkjet transfer paper with original equipment manufacturer inks only. Not recommended for use with generic inks or refilled ink cartridges. Testing on garments that contain polyester is recommended. Some polyesters contain excess dye that may result in dye migration.

Important: Always store unused paper flat, out of direct light, in a cool and dry area, and sealed in a plastic bag so paper is not exposed to any excess moisture.

CREATE DESIGN

When printing design, do not print on side of paper with orange line.

“ For best results, do not cut 11" x 17" in half before printing.

PEEL AWAY PAPER BACKING

Hold image side of transfer toward you, make a small 1/4" (0.5 cm) hard crease on a corner. Flip the transfer over and crease the corner in the opposite direction. Gently tear the paper backing along the crease to separate the transfer from the paper backing. DO NOT tear the transfer film layer.

TRIM TRANSFER

After tearing the corner, separate the layers and slowly peel the transfer just past the image. Stop there and replace the paper backing. Trim around the image. After trimming, gently peel the entire backing away from the image.

PREHEAT AND POSITION

Preheat garment for 5 seconds to remove moisture, chemical treatment and wrinkles. Position trimmed Transjet Opaque transfer on garment, print side up. Cover with Silicone/kraft paper cover sheet.

HEAT APPLY

- Temperature: 280°F (138°C)
- Time: 35 Seconds
- Pressure: Low-Medium
- Peel away kraft paper. CAUTION: HOT

CARE INSTRUCTIONS

- For first time laundering wash garment separately.
- Turn garment inside out.
- Machine wash using warm water and mild detergent.
- Tumble dry low.
- Do not bleach, iron directly onto transfer or dry clean.